# Components of the GN9330e Headset System



### **PUBLIC III**

# **GN9330e Wireless Headset System**

Service and Installation Instructions



### Wireless headset system cpl. comprising: Base station, headband and

earhook incl. patch cable 40.054.376



# Replacement headset

- WITHOUT base station

- WITHOUT wearing accessories -



Ref. 40.030.023

Ref. 40.030.022



#### **Earhook**

Ref. 40.030.024



#### Headband

Ref. 40.030.025



Zeppelinstr. 4 78083 Dauchingen Postfach 11 63 78080 Dauchingen Tel.: +49 7720 9956-0

Fax: +49 7720 9956-22 Email: clarson@clarson.de Internet: http://www.clarson.de












# Standard Connection of the GN9330e Headset System to the microphone loudspeaker unit PUBLIC III - SERVICE SIDE -

Central Unit Ref. 40.054.311 Microphone Loudspeaker Unit Ref. 40.054.301 - bottom side





Ref. 40.054.327 patch cable, 3 m with RJ45 connector (8/8-pin), central unit <--> microphone loudspeaker unit Ref. 40.054.376 patch cable, 3 m with RJ10 connector (4/4-pin), microphone loudspeaker unit <--> GN9330e base station





#### **Base Station**



#### Headset



- Microphone
- Volume control with mute
  - Switchover button to headset mode
- Configuration switch to pos. A
- Headset charge facility
- Connection to PUBLIC III central unit 40.054.311 (to microphone loudspeaker unit 40.054.301 respectively), pages 2/3/4
- A/C power adapter port
- Pairing button ▶◀
- Microphone volume
- Base station

9

Power supply adapter



Wireless headset Ref. 40.030.022







### Pairing of one/several Headset(s) to the GN9330e Base Station

If one of more additional headsets shall be operated from one GN9330e base station, they need to be paired as follows:

#### Important:

Make sure that the connection between primary headset and base station is established.

Push the headset's speech button 6.

The base's Telefone and USB mode indicators should not flash.

A secondary headset is paired as follows:

- Place secondary headset in primary headset's base 10
- Push pairing button ▶ ◀ 16 at the base station. Primary base's telephone and USB mode indicators and secondary headset's link indicator will light for 2 seconds. This means that the secondary headset has been paired successfully (see also page 16 of the GN9330e user manual)



### Optional Connection of the GN9330e Headset System to the Central Unit PUBLIC III - SERVICE SIDE -

Central Unit Ref. 40.054.311









# Standard Connection of the GN9330e Headset System to the Central Unit PUBLIC III - PUBLIC SIDE -

Central Unit Ref. 40.054.311



# Operating Instructions

- Factory Settings at the GN9330e Base Station: Speech volume 17 on approx. 1 o'clock
  - Configuration dial on "A"
- Link socket and of the headset's base station with headset interface of the **PUBLIC III** microphone loudspeaker unit (patch cable 40.054.376) directly with the PUBLIC III headset socket of the central unit (patch cable 40.054.378)
- Connect power supply 22 to base station socket 13. 3.
- Switch on the **PUBLIC III** microphone loudspeaker unit (button ①).
- Remove headset from base station or push button 6:
  - LED above button ① of the microphone loudspeaker unit flashes
  - headset is activated
- Back to standard operating mode:
  - Insert headset into base station 10 or push button 6.
  - Switch the **PUBLIC III** microphone loudspeaker unit off and on again (button ①).
- For all other functions please refer to the **PUBLIC III** service and installation instructions as well as to the GN9330e user manual